










































 Wash	Machine Wash  Regular  Permanent Press/Wrinkle Resistant  Delicate/Gentle	Wash Temperature  Hot (120 F)  Warm (105 F)  Cold/Cool (85 F)
	 Do Not Wash  Hand Wash  Do Not Wring	
 Bleach	 Bleach as Needed  Non-chlorine Bleach as Needed  Do Not Bleach	
 Dry	Dry Cycle  Tumble Dry  Tumble Dry Permanent Press/Wrinkle Resistant  Tumble Dry Gentle/Delicate	Dry Temperature  High  Medium  Low  NO HEAT
	 Do Not Dry  Do Not Tumble Dry	Dry - Additional Instructions  Line Dry  Dry Flat  Drip Dry  In the Shade
 Iron	Iron - Dry or Steam  High  Med  Low	
	 No Iron  No Steam	
 Dry Clean	 Any Solvent  A Any Solvent	Special Dry Clean Instructions  Reduce Moisture  Short Cycle  No Steam Finishing  Low Heat
	 Do Not Dry Clean  F Petroleum Only  P Any Except Trichloroethylene	CAUTION: We cannot clean these items unless there is an alternative cleaning method (e.g. wash/wetclean), or in the case of "P", there is no polyurethane. If in doubt, attach a gray Do Not Dry Clean flag and send in on a hanger.